

## TXX5 A/V Receiver - RS232 Protocol Variables

	Main	Zone2	Zone3	Zone4	Source1 ... 9	Source10	Preset1 ... 5	Tuner	Audyssey	iPod
Model	X									
Version	X									
Serial	X									
Volume	X	X	X	X						
Source	X	X	X	X						
SpeakerA	X									
SpeakerB	X									
Audyssey	X						X			
CenterDialog	X						X			
Treble	X						X			
Bass	X						X			
ToneDefeat	X						X			
Dimmer	X						X			
Dolby.DRC	X						X			
Dolby.CenterWidth	X						X			
Dolby.Dimension	X						X			
Dolby.Panorama	X						X			
DTS.DRC	X						X			
DTS.CenterGain	X						X			
EnhancedStereo.Front	X						X			
EnhancedStereo.Center	X						X			
EnhancedStereo.Surround	X						X			
EnhancedStereo.Back	X						X			
LipSyncDelay	X						X			
Speaker.Front.Config	X						X		X	
Speaker.Front.Frequency	X						X		X	
Speaker.Center.Config	X						X		X	
Speaker.Center.Frequency	X						X		X	
Speaker.Surround.Config	X						X		X	
Speaker.Surround.Frequency	X						X		X	
Speaker.Back.Config1	X						X		X	
Speaker.Back.Config2	X						X		X	
Speaker.Back.Frequency	X						X		X	
Speaker.Sub	X						X		X	
EnhancedBass	X						X			
Level.Left	X						X		X	
Level.Center	X						X		X	
Level.Right	X						X		X	
Level.SurroundRight	X						X		X	
Level.BackRight	X						X		X	
Level.BackLeft	X						X		X	
Level.SurroundLeft	X						X		X	
Level.Sub	X						X		X	
Distance.UOM	X						X			
Distance.Left	X						X		X	
Distance.Center	X						X		X	
Distance.Right	X						X		X	
Distance.SurroundRight	X						X		X	
Distance.BackRight	X						X		X	
Distance.BackLeft	X						X		X	
Distance.SurroundLeft	X						X		X	
Distance.Sub	X						X		X	
Amp.Back	X									
Trigger1.Out	X									
Trigger2.Out	X									
Trigger3.Out	X									
Trigger1.Delay	X									
Trigger2.Delay	X									
Trigger3.Delay	X									
AutoTrigger	X									
VFD.Display	X						X			
VFD.Line1	X						X			
VFD.Line2	X						X			
VFD.TempLine	X						X			
OSD.TempDisplay	X						X			
Power	X	X	X	X						
Mute	X	X	X	X						
ListeningMode	X						X			

Trim.Surround	X									
Trim.Center	X									
Trim.Sub	X									
Sleep	X									
VolumeControl		X	X	X						
VolumeFixed		X	X	X						
Name					X	X	X			
Setup.ListeningMode							X			
Setup.DSPOptions							X			
Setup.ToneControls							X			
Setup.Speaker							X			
Setup.Display							X			
DigitalMode								X		
AMStep								X		
Band								X		
Preset					X	X		X		
AM.Frequency								X		
FM.Frequency								X		
FM.Mute								X		
FM.RDSName								X		
FM.RDSText								X		
Enabled					X	X				X
AnalogAudioFormat					X	X				
AnalogAudioInput					X	X				
AnalogGain					X	X				
DigitalAudioFormat					X	X				
DigitalAudioInput					X	X				
VideoFormat					X	X				
VideoInput					X	X				
TriggerOut					X	X				
DAB.DLS								X		
DAB.Service								X		
IR	X									
Mode			X	X						
ListeningMode.Analog	X						X			
ListeningMode.Digital	X						X			
ListeningMode.DolbyDigital	X						X			
ListeningMode.DolbyDigital2ch	X						X			
ListeningMode.DTS	X						X			
VideoMode	X									
XM.Channel								X		
XM.ChannelName								X		
XM.Name								X		
XM.Title								X		
Preset1 ... 40								X		
AutoConnect										X
Shuffle										X
Repeat										X
MenuTimeout										X
AudiobookSpeed										X