

## NAD Electronics

### C355 RS232 Command List

#### Notes

- Send a Carriage Return <CR> before and after each command
- In addition to using the <=> operator, each [Prefix].[Variable] can be incremented, decremented, or queried by using <+>, <->, or <?> operators.

<b>Main.Model</b>	Operators: ?
-------------------	--------------

N/A

Description: Query Model

Example: <CR>Main.Model?<CR>

<b>Main.Mute</b>	Operators: =/+/-/?
------------------	--------------------

Possible Values:

Off

On

Description: Set Main Mute On/Off

Example: <CR>Main.Mute=Off<CR>

<b>Main.Power</b>	Operators: =/+/-/?
-------------------	--------------------

Possible Values:

On

Off

Description: Set Main Power On/Off

Example: <CR>Main.Power=On<CR>

<b>Main.Source</b>	Operators: =/+/-/?
--------------------	--------------------

Possible Values:

Tuner

CD

Video

Aux

Disc

Ipod

Tape2

Description: Set Source

Example: <CR>Main.Source=Tuner<CR>

<b>Main.SpeakerA</b>	Operators: =/+/-/?
----------------------	--------------------

Possible Values:

Off

On

Description: Set Main Speaker A On/Off

Example: <CR>Main.SpeakerA=Off<CR>

**Main.SpeakerB**

Operators: =/+/-/?

Possible Values:

Off  
On

Description: Set Main Speaker B On/Off

Example: &lt;CR&gt;Main.SpeakerB=Off&lt;CR&gt;

**Main.Tape1**

Operators: =/+/-/?

Possible Values:

On  
Off

Description: Set Tape1 On/Off

Example: &lt;CR&gt;Main.Tape1=On&lt;CR&gt;

**Main.Volume**

Operators: +/-

N/A

Description: Increment / Decrement Volume (No Discrete Values due to motorized volume control)

Example: &lt;CR&gt;Main.Volume+&lt;CR&gt;